

## Wilo-Drain MTS 40

- |            |   |            |                                      |
|------------|---|------------|--------------------------------------|
| <b>D</b>   | Einbau- und Betriebsanleitung                 | <b>H</b>   | Beépítési és üzemeltetési utasítás   |
| <b>GB</b>  | Installation and operating instructions       | <b>PL</b>  | Instrukcja montażu i obsługi         |
| <b>F</b>   | Notice de montage et de mise en service       | <b>CZ</b>  | Návod k montáži a obsluze            |
| <b>NL</b>  | Inbouw- en bedieningsvoorschriften            | <b>GR</b>  | Οδηγίες εγκατάστασης και λειτουργίας |
| <b>E</b>   | Instrucciones de instalación y funcionamiento | <b>TR</b>  | Montaj ve Kullanma Kılavuzu          |
| <b>I</b>   | Istruzioni di montaggio, uso e manutenzione   | <b>RUS</b> | Инструкция по монтажу и эксплуатации |
| <b>S</b>   | Monterings- och skötselinstruktioner          | <b>BG</b>  | Инструкция за монтаж и експлоатация  |
| <b>FIN</b> | Huolto- ja käyttöohje                         | <b>RO</b>  | Instrukcja montazu i obslugi         |
| <b>DK</b>  | Monterings- og driftsvejledning               |            |                                      |

Fig.1:




Fig.2: MTS 40/21...27, DN 32 (R1 ¼)





Fig.3: MTS 40/21...39, DN 40 (R1 ½)



<b>D</b>	Einbau- und Betriebsanleitung	3
<b>GB</b>	Installation and operating instructions	9
<b>F</b>	Notice de montage et de mise en service	15
<b>NL</b>	Inbouw- en bedieningsvoorschriften	21
<b>E</b>	Instrucciones de instalación y funcionamiento	27
<b>I</b>	Istruzioni di montaggio, uso e manutenzione	33
<b>S</b>	Monterings- och skötselanvisning	39
<b>FIN</b>	Huolto- ja käyttöohje	44
<b>DK</b>	Monterings- og driftsvejledning	49
<b>H</b>	Beépítési és üzemeltetési utasítás	54
<b>PL</b>	Instrukcja montażu i obsługi	60
<b>CZ</b>	Návod k montáži a obsluze	66
<b>GR</b>	Οδηγίες εγκατάστασης και λειτουργίας	72
<b>TR</b>	Montaj ve Kullanma Kılavuzu	78
<b>RUS</b>	Инструкция по монтажу и эксплуатации	83
<b>BG</b>	Инструкция за монтаж и експлоатация	90
<b>RO</b>	Instrucțiuni de montaj și exploatare	96



## 1 General

### 1.1 About this document

These installation and operating instructions are an integral part of the product. They must be kept readily available at the place where the product is installed. Strict adherence to these instructions is a precondition for the proper use and correct operation of the product.

These installation and operating instructions conform to the relevant version of the product and the underlying safety standards valid at the time of going to press.

## 2 Safety

These instructions contain important information which must be followed when installing and operating the pump. It is therefore imperative that they be read by both the installer and the operator before the pump is installed or operated.

Both the general safety instructions in this section and the more specific safety points in the following sections should be observed.

### 2.1 Instruction symbols used in this operating manual

**Symbols:**



**General danger symbol**



**Hazards from electrical causes**



**NOTE: ...**

**Signal words:**

**DANGER!**

**Imminently hazardous situation.**

**Will result in death or serious injury if not avoided.**

**WARNING!**

**Risk of (serious) injury. 'Warning' implies that failure to comply with the safety instructions is likely to result in (severe) personal injury.**

**CAUTION!**

**Risk of damage to the pump/installation. 'Caution' alerts to user to potential product damage due to non-compliance with the safety instructions**

**NOTE:**

Useful information on the handling of the product. It alerts the user to potential difficulties

### 2.2 Personnel qualification

The personnel installing the pump must have the appropriate qualification for this work.

### 2.3 Risks incurred by failure to comply with the safety instructions

Failure to comply with the safety precautions could result in personal injury or damage to the pump or installation. Failure to comply with the safety precautions could also invalidate any claim for damages.

In particular, failure to comply with these safety instructions could give rise, for example, to the following risks:

- Failure of important pump or system functions,
- Failure of specified maintenance and repair methods
- Personal injury due to electrical, mechanical and bacteriological causes.
- Damage to property

### 2.4 Safety instructions for the operator

The relevant accident precaution regulations must be observed.

Potential dangers caused by electrical energy must be excluded. Local or general regulations [e.g. IEC, VDE, etc.] and directives from local energy supply companies are to be followed.

### 2.5 Safety instructions for inspection and assembly

The operator must ensure that all inspection and assembly work is carried out by authorised and qualified specialists who have carefully studied these instructions.

Work on a pump or installation should only be carried out once the latter has been brought to a standstill.

### 2.6 Unauthorised modification and manufacture of spare parts

Changes to the pump/machinery may only be made in agreement with the manufacturer. The use of original spare parts and accessories authorised by the manufacturer will ensure safety. The use of any other parts may invalidate claims invoking the liability of the manufacturer for any consequences.

### 2.7 Improper use

The operating safety of the pump or installation can only be guaranteed if it is used in accordance with paragraph 4 of the operating instructions. All values must neither exceed nor fall below the limit values given in the catalogue or data sheet.

### 3 Transport and interim storage

Inspect the pump/system for transport damage immediately upon arrival. Any transport damage found must be reported to the carrier within the prescribed periods.



#### CAUTION! Risk of damage to the pump!

**Risk of damage due to improper handling during transport or storage.**

- The pump may only be hung from or carried using the handle provided for transport. Never suspend or carry using the cable!
- The pump should be protected against moisture, frost and physical damage during transport and interim storage.

### 4 Applications



#### WARNING! Health hazard!

**The materials are not designed for drinking water supply.**

**The pump must not be used for pumping drinking water.**

The submersible motor-driven pump is suitable for transporting sewage from shafts and tanks. It is used primarily for pressure drainage of sewage water for domestic purposes (according to EN 12056 in compliance with the country-specific prefaces and regulations).



#### CAUTION! Risk of damage to the pump!

**The pump is not suitable for use with flow media containing solids such as sand, stones or metals.**

## 5 Product data

### 5.1 Type code

Example: MTS 40/27-1-230-50-2

MT	MT = Series MT (Macerator Technology)
S	S = Stainless Steel Motor
40	Nominal width discharge side [mm]
/27	Maximum delivery head [m] where Q=0
-1-230	single-phase motor 1~230 V
-50	Mains frequency 50 Hz
-2	2 poles

### 5.2 Technical data

Mains voltage	1~230 V, ±10 % (EM = single-phase motor) 3~400 V, ±10 % (DM = three-phase motor)
Frequency	50 Hz
Protection	IP 68
Insulation class	F
Speed	Max. 2900 1/min
Power input P1 (EM/DM)	see rating plate
Motor power rating P2 (EM/DM)	see rating plate
Nominal current	see rating plate
Winding protection contact (break contact)	$U_{max}=250$ V AC, $I_{max}=1$ A
Max. contact load	$U_{max}=30$ V DC, $I_{max}=30$ mA DC
Permissible medium temp. Min / max	+3°C to 40°C
Max. flow rate	see rating plate
Max. delivery head	see rating plate
Max. immersion depth	10 m
Operating mode S3 (optimum), motor immersed	Intermittent service S3, 25% (2.5 min. mode, 7.5 min. break).
Operating mode S1 (optional), motor immersed	MTS 40/... S1: 200 hrs/year
Explosion protection	EEx d IIB T4
Oil-filled seal chamber	Marcol 82 (medical white oil)
Oil quantity	MTS 40/... 150 ml

### 5.3 Scope of supply

- Pump with 10 m connecting cable:
  - DM version with free cable end (H07 RN-F 6x1 mm<sup>2</sup>)
  - EM version ready-wired (H07 RN-F 4x1.5 mm<sup>2</sup>) with connector box incl. start-up/operating capacitor
- Installation and Operating Instructions

### 5.4 Accessories

Accessories must be ordered separately.

- Switchgear for 1 or 2-pump operation
- external monitoring devices / tripping units
- level controller (level sensor / float switch)
- Accessories for transportable wet-well installation
- Accessories for stationary wet-well installation see catalogue for detailed list.

## 6 Description and operation

### 6.1 Pump description

In order to ensure that the pump remains sufficiently cool in continuous mode, the submersible motor-driven pump must always be flooded with the flow medium. The pump is driven by an encased three-phase or single-phase motor which is corrosion-resistant and impermeable to pressurised water.

The pump housing and single-channel impeller are made from grey cast iron. The flow medium is sucked in on the underside of the pump through the openings on the cutting device and is expelled through the discharge side into the pipe.

The cutting device cuts up all dissectible constituents so that they can be transported through the single-channel impeller and the DN 40 pressure pipe. The blades, cutters and counter-cutters are made of hard metal. Constituents which cannot be cut, such as stones or pieces of metal, damage the cutting device and should therefore not be allowed into the pump.

The motor chamber is sealed from the pump chamber using a mechanical seal on the fluid side and a radial shaft seal on the motor side. To ensure that the mechanical seal is always lubricated and cooled, even when running dry, the mechanical seal chamber is filled with oil (see also 5.2).

#### **CAUTION! Risk of leak!**

**If the mechanical seal is damaged, small quantities of oil may leak into the flow medium.**

In addition to being connected by a foot bend DN 40, the MTS 40 pumps can also be connected to the pressure pipe using an elbow pipe (inner/outer thread):

- Pressure pipe DN32 (R1 ¼): MTS40/21...27 using an 90° elbow pipe (inner/outer thread) R1 ¼.
- Pressure pipe DN40 (R1 ½): MTS40/21...39 using an 90° elbow pipe (inner/outer thread) R1 ½ and threaded flange with neck as per DIN 2566 with inner thread R1 ½.



The motors are equipped with a winding protection contact (WSK) that automatically switches off the motor if there is a threat of it overheating and switches it back on again once it has cooled down. On 3~motors, the winding protection contact must be connected to the switchgear and analysed there.

## 7 Installation and electrical connection

**Installation and electrical connection should be carried out in accordance with local regulations and only by qualified personnel!**

**WARNING! Risk of personal injury!**

**The relevant accident precaution regulations must be observed.**

**WARNING! Risk of electric shock!**

**Potential dangers caused by electrical energy must be excluded.**

**Local or general regulations [e.g. IEC, VDE, etc.] and directives from local energy supply companies are to be followed.**



### 7.1 Installation

The pump is designed for the following installation types: stationary and transportable wet-well installation.



**CAUTION! Risk of damage to the pump!**

**The pump must only be suspended by a chain from the handle provided. Never suspend or carry using the cable!**

- The pump must be installed in a frost-free place.
- The shaft must be free from coarse solids (e.g. building rubble) prior to installation and commissioning.
- The pipes must be assembled stress-free. The pipes must be attached in such a way that the pump does not bear the weight of the pipes.
- In order to protect against possible reflux from the public sewage system, the pressure pipeline should be formed as a "pipe loop". It must be placed over the locally set reflux level (usually street level).
- When assembling the pump for stationary use, a non-return valve and a shut-off valve with full flow cross-section should be built into the pressure piping. In the case of double pumps these fittings should be installed for each pump.

NOTE:

Optimally, the valves should be installed outside of the pump, in a separate shaft (valves shaft). Where this is not feasible, the valves should not be connected directly to the discharge side or the pipe bend. A device for venting the pump should be provided, otherwise the insulating air cushion may not open the non-return valve.

- "Original Wilo accessories" are recommended to ensure the fault-free operation of the pump / installation.



### 7.1.1 Stationary wet-well installation

- Stationary wet-well installation (Fig. 1). Legend to Fig. 1:
  - 1: **Foot bend** with pump mounting, profiled gasket, assembly and base fixing screws and pipe tensioner (Pos. 1.1) for two pipes. The guide pipes (R $\frac{3}{4}$ " =  $\varnothing$ 26.9 to DIN 2440) are to be obtained by the customer.
  - 2: **Backflow preventer** with unrestricted passage, cleaning opening, ventilating device and assembly accessories
  - 3: **Shut-off valve** with fitting accessories
  - 4: **Pipe bend** with fitting accessories
  - 6: **Chain**  
See catalogue for details.
- The fixed pipe connections on the pressure side are to be provided by the customer.
- Fit and align the foot bend on the base of the shaft with the base fastening accessories.
- Connect the pressure piping to the foot bend with the required fittings (accessories).
- Attach the pump mounting and profiled gasket to the pump pressure pipe connection.
- Attach the R $\frac{3}{4}$ " guide pipe (to be provided by the customer) to the foot bend.
- Hang the pump from the guide pipe and carefully lower it on the chain. The pump will lock into the right operating position automatically and seal the delivery connection on the foot bend by its own weight.
- Fasten the chain to the guide pipe mounting with a shackle (provided by the customer).

### 7.1.2 Transportable wet-well installation



#### CAUTION! Risk of damage to the pump!

**The pump should be prevented from falling over or moving away from the spot where it has been installed.**

- Transportable wet-well installation MTS 40/21...27 (Fig. 2).
  - 6: **Chain**
  - 9: **Stand** with fixing accessories
- 10a: **Pipe bend** R1  $\frac{1}{4}$  (inner/outer thread) with fitting accessories  
See catalogue for details.
- Transportable wet-well installation MTS 40/21...39 (Fig. 3).
  - 6: **Chain**
  - 9: **Stand** with fixing accessories
- 10b: **Pipe bend** R1  $\frac{1}{2}$  (inner/outer thread) with flange and fitting accessories.  
See catalogue for details.

### 7.2 Electrical connection



#### WARNING! Risk of electric shock!

**Electrical connection must be carried out by an electrical installer authorised by the local power supply company in accordance with the applicable local regulations (e.g. VDE regulations).**

- Check that the mains current and voltage comply with the data on the rating plate.
- Pump must be earthed in compliance with regulations.

- Use a residual current operating device  $\leq$  30 mA,
- Use a disconnecting device to disconnect from the mains with a contact gap width of min. 3 mm,
- Fuse protection: 16 A, inert or circuit breaker with C-characteristic,
- The switch box for the pump(s) must be provided as an accessory or by the customer, and must be equipped with a protective motor switch which is to be set to the nominal motor current as indicated on the rating plate plus approx. twenty percent.
- Generally speaking, all switch boxes should be installed outside the explosive area.
- Connecting cables should be connected to the leads as follows:

#### Pump with three-phase current motor (3~400V):

For the three-phase current connection (DM), the leads of the free cable end are to be assigned as follows:

MTS 40/...: 6-lead connection cable 6x1.0 mm<sup>2</sup>

Lead no.	Binder
1	U
2	V
3	W
green/yellow	PE
4	T1 (WSK)
5	T2 (WSK)

The free cable end is to be wired up in the switch box (see switch box Installation and Operating Instructions).

#### Pump with single-phase current motor (1~230V):

- Single-phase current connection (EM): The motor is already factory-wired to the terminal box. The mains connection is made via terminals L, N, PE.
- In acc. with DIN EN / IEC 61000-3-11 the pump is to be provided with a rating of 1.5 kW for operation in a power supply with a system impedance  $Z_{max}$  on a line connection of max. 0.125 (0.086) Ohm at a maximum number of 6 (20) switching operations.

If the supply impedance and the number of switching operations per hour exceed the above-mentioned values, the pump can lead to transient voltage reductions and interfering voltage fluctuations, or "flicker", because of the unfavourable supply conditions.

Measures may therefore be required before the pump can be operated properly on this connection; relevant information is to be obtained from the local electricity company (EVU) and the pump manufacturer.



## 8 Starting-up



**WARNING! Risk of injury!**

**Danger – rotating cutter! First switch off the pump!**



**CAUTION! Risk of damage to the pump!**  
Prior to starting up the pump, the shaft and the intake pipes should be freed from solid matter such as rubbish.

### 8.1 Direction of rotation (only for three-phase motors)

The correct direction of rotation must be tested **before** the pump is submerged. This is indicated by the arrow showing the direction of rotation on the pump housing.

- Hang the pump in the hoist.
- Briefly switch on the pump. The pump will move in the opposite direction to the motor (arrow on housing).
- If the direction of rotation is incorrect, 2 phases of the mains connection must be exchanged.

### 8.2 Adjusting the control level

Adjusting the control level: see instructions for assembly and installation of the control level.



**CAUTION! Risk of damage to the pump!**  
**Dry running destroys the mechanical seal.**  
**The pump must not be allowed to run dry and to suck any air.**

The "OFF" position ( $H_{min}$ ) of the level control depends on the pump type and/or the operating mode (Fig. 1, 2, 3).

Type of operation: S1, S3

Pump	$H_{min}$ [mm]
MTS 40/21...27	467
MTS 40/31...39	500

The "ON" position should be set to the desired maximum level but should nevertheless remain below the intake pipe in the shaft.

### 8.3 Operating conditions in potentially explosive locations

See additional instructions for operation for in potentially explosive locations.

## 9 Maintenance

Maintenance and repair work should only be carried out by qualified personnel!



**DANGER! Risk of asphyxiation!**  
Shafts for wastewater submersible motor-driven pumps may contain wastewater with toxic and/or harmful substances.

- For reasons of safety, maintenance work should only be carried out in the presence of another person.
  - The pump shaft must be properly ventilated before any work takes place.
- WARNING! Risk of infection!**  
In order to avoid any risk of infection, maintenance work should only be carried out using appropriate protective clothing (protective gloves).
- WARNING! Risk of electric shock!**  
Potential dangers caused by electrical energy must be excluded.
- The pump must be switched off for all repair work and secured against unauthorised operation.
  - In principle, damage to the connecting cable should only be repaired by a qualified electrician.



### Checking and cleaning the pump:

- The lifetime of the pump depends on the operating conditions and consequently varies greatly. The pump should be inspected at regular intervals. In the case of increasing operating noise, vibrations in the pipework or a drop in conveying capacity, the impeller, with built-in cutter, must be checked for obstructions caused by solid matter and wear.

### Cleaning:

- Remove coarse impurities from the cutter's inlet channels.
- Next, rinse out the cutter's inlet channels. Rinse the pump housing via the discharge side until no more impurities emerge from the cutter's inlet channels.
- Check the cutter's blade clearance: Visually check the cutting edges for damage such as scoring, broken-off parts and the like. Check the blade clearance using a 0.1mm feeler gauge. If the blade is damaged or the clearance has increased (>0.1mm) due to wear, please contact a specialist dealer or the nearest Wilo customer service centre or representative.
- Restart the pump.

### Protection against frost:

- If it cannot be ensured that the flow medium in the pump will not freeze, the pump should be protected against frost.  
We would recommend that the pump be maintained and checked thoroughly by Wilo customer services once every six months.  
Maintenance shall be carried out in accordance with EN12056 Part 4.

## 10 Problems, causes and remedies

Problems	Causes	Remedy
Pump does not run	Interruption of the current, short circuit, Insulation fault in the motor winding	Check power supply, Call on expert to check cable and motor
	Safety fuse, capacitor defect	Replace fuses, capacitor
	Cable break	Check cable resistance. If necessary, replace cable. Only use original Wilo special cable!
	Level switch does not switch	Check level switch
Protective motor switch engaged	Protective motor switch not set correctly	Switch to nominal current
	Cutting device or impeller already blocked by foreign bodies	<ul style="list-style-type: none"> <li>• Switch off the pump voltage and secure against re-operation.</li> <li>• Close the shut-off valve at the back of the pump.</li> <li>• Remove pump from the sump</li> <li>• Remove foreign bodies from the pump</li> </ul>
Pump does not pump	Air in spiral housing	Ventilate backflow preventer
	Level switch not set correctly	Ensure that the suction impeller is flooded
Pump transports too little,	Wrong direction of rotation	interchange two phases of the mains connection
noisy operation	Impeller worn down	Change impeller
	Impeller, cutting device or pump housing covered in sludge	Clean pump, see sixth line

**If no solution can be found, please contact your plumbing and heating specialist or your nearest Wilo Customer Service or representative.**

## 11 Spare parts

Spare parts are ordered via a local specialist dealer and/or Wilo customer service.

In order to avoid queries and incorrect orders, make sure to mention all data indicated on the rating plate when placing your order.

**Subject to technical alterations!**

**D** **EG – Konformitätserklärung**  
**GB** **EC – Declaration of conformity**  
**F** **Déclaration de conformité CE**

Hiermit erklären wir, dass die Bauarten der Baureihe : **MTS 40/...**  
*Herewith, we declare that this product:* **MTS 40 E ...**  
*Par le présent, nous déclarons que cet agrégat :*

in der gelieferten Ausführung folgenden einschlägigen Bestimmungen entspricht:  
*in its delivered state comply with the following relevant provisions:*  
*est conforme aux dispositions suivants dont il relève:*

**EG-Maschinenrichtlinie** **98/37/EG**  
**EC-Machinery directive**  
**Directives CE relatives aux machines**

**Elektromagnetische Verträglichkeit – Richtlinie** **2004/108/EG**  
**Electromagnetic compatibility – directive**  
**Compatibilité électromagnétique- directive**

**Niederspannungsrichtlinie** **2006/95/EG**  
**Low voltage directive**  
**Directive basse-tension**

**Bauproduktenrichtlinie** **89/106/EWG**  
**Construction product directive** *i.d.F/ as amended/ avec les amendements suivants :*  
**Directive de produit de construction** **93/68/EWG**

und entsprechender nationaler Gesetzgebung.  
*and with the relevant national legislation.*  
*et aux législations nationales les transposant.*

Angewendete harmonisierte Normen, insbesondere: **EN 809** **EN 60335-2-41**  
*Applied harmonized standards, in particular:* **EN 12050-1** **EN 61000-3-2**  
*Normes harmonisées, notamment:* **EN 55014-1** **EN 61000-3-3**  
**EN 60034-1** **DIN EN 12050-1**  
**EN 60204-1**



Bei einer mit uns nicht abgestimmten technischen Änderung der oben genannten Bauarten, verliert diese Erklärung ihre Gültigkeit.  
*If the above mentioned series are technically modified without our approval, this declaration shall no longer be applicable.*  
*Si les gammes mentionnées ci-dessus sont modifiées sans notre approbation, cette déclaration perdra sa validité.*

Dortmund, 03.03.2009

*i. V.*  
  
Erwin Prieß  
Quality Manager



WILO SE  
Nortkirchenstraße 100  
44263 Dortmund  
Germany

<p><b>NL EG-verklaring van overeenstemming</b> Hiermede verklaren wij dat dit aggregaat in de geleverde uitvoering voldoet aan de volgende bepalingen: EG-richtlijnen betreffende machines 98/37/EG Elektromagnetische compatibiliteit 2004/108/EG EG-laagspanningsrichtlijn 2006/95/EG Bouwproductenrichtlijn 89/106/EEG als vervolg op 93/86/EEG Gebruikte geharmoniseerde normen, in het bijzonder: <b>1)</b></p>	<p><b>I Dichiarazione di conformità CE</b> Con la presente si dichiara che i presenti prodotti sono conformi alle seguenti disposizioni e direttive rilevanti: Direttiva macchine 98/37/CE Compatibilità elettromagnetica 2004/108/EG Direttiva bassa tensione 2006/95/EG Direttiva linee guida costruzione dei prodotti 89/106/CEE e seguenti modifiche 93/68/CEE Norme armonizzate applicate, in particolare: <b>1)</b></p>	<p><b>E Declaración de conformidad CE</b> Por la presente declaramos la conformidad del producto en su estado de suministro con las disposiciones pertinentes siguientes: Directiva sobre máquinas 98/37/CE Directiva sobre compatibilidad electromagnética 2004/108/EG Directiva sobre equipos de baja tensión 2006/95/EG Directiva sobre productos de construcción 89/106/CEE modificada por 93/68/CEE Normas armonizadas adoptadas, especialmente: <b>1)</b></p>
<p><b>P Declaração de Conformidade CE</b> Pela presente, declaramos que esta unidade no seu estado original, está conforme os seguintes requisitos: Directivas CEE relativas a máquinas 98/37/CE Compatibilidade electromagnética 2004/108/EG Directiva de baixa voltagem 2006/95/EG Directiva sobre produtos de construção 89/106/CEE com os aditamentos seguintes 93/68/EEG Normas harmonizadas aplicadas, especialmente: <b>1)</b></p>	<p><b>S CE- försäkran</b> Härmed förklarar vi att denna maskin i levererat utförande motsvarar följande tillämpliga bestämmelser: EG-Maskindirektiv 98/37/EG EG-Elektromagnetisk kompatibilitet – riktlinje 2004/108/EG EG-Lågspänningsdirektiv 2006/95/EG EG-Byggmaterialdirektiv 89/106/EEG med följande ändringar 93/68/EEG Tillämpade harmoniserade normer, i synnerhet: <b>1)</b></p>	<p><b>N EU-Overensstemmelseserklæring</b> Vi erklærer hermed at denne enheten i utførelse som levert er i overensstemmelse med følgende relevante bestemmelser: EG-Maskindirektiv 98/37/EG EG-EMV-Elektromagnetisk kompatibilitet 2004/108/EG EG-Lavspenningsdirektiv 2006/95/EG Byggevaredirektiv 89/106/EEG med senere tilføyelser 93/68/EEG Anvendte harmoniserte standarder, særlig: <b>1)</b></p>
<p><b>FIN CE-standardinmukaisuuslause</b> Ilmoitamme täten, että tämä laite vastaa seuraavia asiaankuuluvia määräyksiä: EU-konedirektiivit: 98/37/EG Sähkömagneettinen soveltuvuus 2004/108/EG Matalajännite direktiivit: 2006/95/EG EU materiaalidirektiivi 89/106/EEG seuraavin täsmennyksin 93/68/EEG Käytetyt yhteensovitettut standardit, erityisesti: <b>1)</b></p>	<p><b>DK EF-overensstemmelseserklæring</b> Vi erklærer hermed, at denne enhed ved levering overholder følgende relevante bestemmelser: EU-maskindirektiver 98/37/EG Elektromagnetisk kompatibilitet: 2004/108/EG Lavvolts-direktiv 2006/95/EG Produktkonstruktionsdirektiv 98/106/EEG følgende 93/68/EEG Anvendte harmoniserede standarder, særligt: <b>1)</b></p>	<p><b>H EK. Azonossági nyilatkozat</b> Ezennel kijelentjük, hogy az berendezés az alábbiaknak megfelel: EK Irányelvek gépekhez: 98/37/EG Elektromágneses zavarás/tűrés: 2004/108/EG Kisfeszültségű berendezések irány-Elve: 2006/95/EG Építési termékek irányelv 98/106/EEG és az azt kiegészítő 93/68/EEG Felhasznált harmonizált szabványok, különösen: <b>1)</b></p>
<p><b>CZ Prohlášení o shodě EU</b> Prohlašujeme tímto, že tento agregát v dodaném provedení odpovídá následujícím příslušným ustanovením: Směrnícím EU–strojní zařízení 98/37/EG Směrnícím EU–EMV 2004/108/EG Směrnícím EU–nízké napětí 2006/95/EG Směrnícím stavebních produktů 89/106/EEG ve sledu 93/68/EEG Použité harmonizační normy, zejména: <b>1)</b></p>	<p><b>PL Deklaracja Zgodności CE</b> Niniejszym deklaruujemy z pełną odpowiedzialnością że dostarczony wyrób jest zgodny z następującymi dokumentami: EC–dyrektywa dla przemysłu maszynowego 98/37/EG Odpowiedniość elektromagnetyczna 2004/108/EG Normie niskich napięć 2006/95/EG Wyroby budowlane 89/106/EEG ze zmianą 93/68/EEG Wyroby są zgodne ze szczegółowymi normami zharmonizowanymi: <b>1)</b></p>	<p><b>RUS Декларация о соответствии Европейским нормам</b> Настоящим документом заявляем, что данный агрегат в его объеме поставки соответствует следующим нормативным документам: Директивы ЕС в отношении машин 98/37/EG Электромагнитная устойчивость 2004/108/EG Директивы по низковольтному напряжению 2006/95/EG Директива о строительных изделиях 89/106/EEG с поправками 93/68/EEG Используемые согласованные стандарты и нормы, в частности: <b>1)</b></p>
<p><b>GR Δήλωση προσαρμογής της Ε.Ε.</b> Δηλώνουμε ότι το προϊόν αυτό σ' αυτή την κατάσταση παράδοσης ικανοποιεί τις ακόλουθες διατάξεις: Οδηγίες EG για μηχανήματα 98/37/EG Ηλεκτρομαγνητική συμβατότητα EG–2004/108/EG Οδηγία χαμηλής τάσης EG–2006/95/EG Οδηγία κατασκευής 89/106/EEG όπως τροποποιήθηκε 93/68/EEG Εναρμονισμένα χρησιμοποιούμενα πρότυπα, ιδιαίτερα: <b>1)</b></p>	<p><b>TR CE Uygunluk Teyid Belgesi</b> Bu cihazın teslim edildiği şekliyle aşağıdaki standartlara uygun olduğunu teyid ederiz: AB-Makina Standartları 98/37/EG Elektromanyetik Uyumluluk 2004/108/EG Alçak gerilim direktifi 2006/95/EG Ürün imalat direktifi 89/106/EEG ve takip eden, 93/68/EEG Kısmen kullanılan standartlar: <b>1)</b></p>	<p><b>1) EN 809 EN 12050-1 EN 55014-1 EN 60034-1 EN 60204-1 EN 60335-2-41 EN 61000-3-2 EN 61000-3-3 DIN EN 12050-1</b></p>
<div style="display: flex; justify-content: space-between; align-items: center;"> <div style="text-align: center;">   <b>Erwin Prieß</b>  <b>Quality Manager</b> </div> <div style="text-align: right;">   <b>WILO SE</b>  <b>Nortkirchenstraße 100</b>  <b>44263 Dortmund</b>  <b>Germany</b> </div> </div>		



WILO SE  
Nortkirchenstraße 100  
44263 Dortmund  
Germany  
T +49 231 4102-0  
F +49 231 4102-7363  
wilo@wilo.com  
www.wilo.com

## Wilo – International (Subsidiaries)

### Argentina

WILO SALMSON  
Argentina S.A.  
C1270ABE Ciudad  
Autónoma de Buenos Aires  
T +54 11 43015955  
info@salmon.com.ar

### Austria

WILO Pumpen  
Österreich GmbH  
1230 Wien  
T +43 507 507-0  
office@wilo.at

### Azerbaijan

WILO Caspian LLC  
1065 Baku  
T +994 12 5962372  
info@wilo.az

### Belarus

WILO Bel OOO  
220035 Minsk  
T +375 17 2503393  
wilobel@wilo.by

### Belgium

WILO SA/NV  
1083 Ganshoren  
T +32 2 4823333  
info@wilo.be

### Bulgaria

WILO Bulgaria Ltd.  
1125 Sofia  
T +359 2 9701970  
info@wilo.bg

### Canada

WILO Canada Inc.  
Calgary, Alberta T2A 5L4  
T +1 403 2769456  
bill.lowe@wilo-na.com

### China

WILO China Ltd.  
101300 Beijing  
T +86 10 80493900  
wilobj@wilo.com.cn

### Croatia

WILO Hrvatska d.o.o.  
10090 Zagreb  
T +38 51 3430914  
wilo-hrvatska@wilo.hr

### Czech Republic

WILO Praha s.r.o.  
25101 Cestlice  
T +420 234 098711  
info@wilo.cz

### Denmark

WILO Danmark A/S  
2690 Karlslunde  
T +45 70 253312  
wilo@wilo.dk

### Estonia

WILO Eesti OÜ  
12618 Tallinn  
T +372 6509780  
info@wilo.ee

### Finland

WILO Finland OY  
02330 Espoo  
T +358 207401540  
wilo@wilo.fi

### France

WILO S.A.S.  
78390 Bois d'Arcy  
T +33 1 30050930  
info@wilo.fr

### Great Britain

WILO (U.K.) Ltd.  
DE14 2WJ Burton-  
Upon-Trent  
T +44 1283 523000  
sales@wilo.co.uk

### Greece

WILO Hellas AG  
14569 Anixi (Attika)  
T +302 10 6248300  
wilo.info@wilo.gr

### Hungary

WILO Magyarország Kft  
2045 Törökbálint  
(Budapest)  
T +36 23 889500  
wilo@wilo.hu

### Ireland

WILO Engineering Ltd.  
Limerick  
T +353 61 227566  
sales@wilo.ie

### Italy

WILO Italia s.r.l.  
20068 Peschiera  
Borromeo (Milano)  
T +39 25538351  
wilo.italia@wilo.it

### Kazakhstan

WILO Central Asia  
050002 Almaty  
T +7 727 2785961  
in.pak@wilo.kz

### Korea

WILO Pumps Ltd.  
621-807 Gimhae  
Gyeongnam  
T +82 55 3405800  
wilo@wilo.co.kr

### Latvia

WILO Baltic SIA  
1019 Riga  
T +371 67 145229  
mail@wilo.lv

### Lebanon

WILO SALMSON  
Lebanon  
12022030 El Metn  
T +961 4 722280  
wsl@cyberia.net.lb

### Lithuania

WILO Lietuva UAB  
03202 Vilnius  
T +370 5 2136495  
mail@wilo.lt

### The Netherlands

WILO Nederland b.v.  
1551 NA Westzaan  
T +31 88 9456 000  
info@wilo.nl

### Norway

WILO Norge AS  
0975 Oslo  
T +47 22 804570  
wilo@wilo.no

### Poland

WILO Polska Sp. z o.o.  
05-090 Raszyn  
T +48 22 7026161  
wilo@wilo.pl

### Portugal

Bombas Wilo-Salmson  
Portugal Lda.  
4050-040 Porto  
T +351 22 2080350  
bombas@wilo.pt

### Romania

WILO Romania s.r.l.  
077040 Com. Chiajna  
Jud. Ilfov  
T +40 21 3170164  
wilo@wilo.ro

### Russia

WILO Rus ooo  
123592 Moscow  
T +7 495 7810690  
wilo@orc.ru

### Saudi Arabia

WILO ME – Riyadh  
Riyadh 11465  
T +966 1 4624430  
wshoula@watanaiind.com

### Serbia and Montenegro

WILO Beograd d.o.o.  
11000 Beograd  
T +381 11 2851278  
office@wilo.co.yu

### Slovakia

WILO Slovakia s.r.o.  
82008 Bratislava 28  
T +421 2 45520122  
wilo@wilo.sk

### Slovenia

WILO Adriatic d.o.o.  
1000 Ljubljana  
T +386 1 5838130  
wilo.adriatic@wilo.si

### South Africa

Salmson South Africa  
1610 Edenvale  
T +27 11 6082780  
erro.l.cornelius@  
salmson.co.za

### Spain

WILO Ibérica S.A.  
28806 Alcalá de Henares  
(Madrid)  
T +34 91 8797100  
wilo.iberica@wilo.es

### Sweden

WILO Sverige AB  
35246 Växjö  
T +46 470 727600  
wilo@wilo.se

### Switzerland

EMB Pumpen AG  
4310 Rheinfelden  
T +41 61 83680-20  
info@emb-pumpen.ch

### Taiwan

WILO-EMU Taiwan Co. Ltd.  
110 Taipei  
T +886 227 391655  
nelson.wu@  
wiloemutaiwan.com.tw

### Turkey

WILO Pompa Sistemleri  
San. ve Tic. A.Ş.  
34530 Istanbul  
T +90 216 6610211  
wilo@wilo.com.tr

### Ukraine

WILO Ukraina t.o.w.  
01033 Kiev  
T +38 044 2011870  
wilo@wilo.ua

### Vietnam

Pompes Salmson Vietnam  
Ho Chi Minh-Ville Vietnam  
T +84 8 8109975  
nkm@salmson.com.vn

### United Arab Emirates

WILO ME – Dubai  
Dubai  
T +971 4 3453633  
info@wilo.com.sa

### USA

WILO-EMU USA LLC  
Thomasville,  
Georgia 31792  
T +1 229 5840097  
info@wilo-emu.com

### USA

WILO USA LLC  
Melrose Park, Illinois 60160  
T +1 708 3389456  
mike.easterley@  
wilo-na.com

## Wilo – International (Representation offices)

### Algeria

Bad Ezzouar, Dar El Beida  
T +213 21 247979  
chabane.hamdad@salmson.fr

### Armenia

375001 Yerevan  
T +374 10 544336  
info@wilo.am

### Bosnia and Herzegovina

71000 Sarajevo  
T +387 33 714510  
zeljko.cvjetkovic@wilo.ba

### Georgia

0179 Tbilisi  
T +995 32 306375  
info@wilo.ge

### Macedonia

1000 Skopje  
T +389 2 3122058  
valerij.vojneski@wilo.com.mk

### Mexico

07300 Mexico  
T +52 55 55863209  
roberto.valenzuela@wilo.com.mx

### Moldova

2012 Chisinau  
T +373 2 223501  
sergiu.zagurean@wilo.md

### Rep. Mongolia

Ulaanbaatar  
T +976 11 314843  
wilo@magicnet.mn

### Tajikistan

734025 Dushanbe  
T +992 37 2232908  
farhod.rahimov@wilo.tj

### Turkmenistan

744000 Ashgabad  
T +993 12 345838  
wilo@wilo-tm.info

### Uzbekistan

100015 Tashkent  
T +998 71 1206774  
info@wilo.uz

January 2009



WILO SE  
Nortkirchenstraße 100  
44263 Dortmund  
Germany  
T 0231 4102-0  
F 0231 4102-7363  
wilo@wilo.com  
www.wilo.de

## Wilo-Vertriebsbüros in Deutschland

### G1 Nord

WILO SE  
Vertriebsbüro Hamburg  
Beim Strohhouse 27  
20097 Hamburg  
T 040 5559490  
F 040 55594949  
hamburg.anfragen@wilo.com

### G3 Ost

WILO SE  
Vertriebsbüro Dresden  
Frankenring 8  
01723 Kesselsdorf  
T 035204 7050  
F 035204 70570  
dresden.anfragen@wilo.com

### G5 Süd-West

WILO SE  
Vertriebsbüro Stuttgart  
Hertichstraße 10  
71229 Leonberg  
T 07152 94710  
F 07152 947141  
stuttgart.anfragen@wilo.com

### G7 West

WILO SE  
Vertriebsbüro Düsseldorf  
Westring 19  
40721 Hilden  
T 02103 90920  
F 02103 909215  
duesseldorf.anfragen@wilo.com

### G2 Nord-Ost

WILO SE  
Vertriebsbüro Berlin  
Juliusstraße 52-53  
12051 Berlin-Neukölln  
T 030 6289370  
F 030 62893770  
berlin.anfragen@wilo.com

### G4 Süd-Ost

WILO SE  
Vertriebsbüro München  
Adams-Lehmann-Straße 44  
80797 München  
T 089 4200090  
F 089 42000944  
muenchen.anfragen@wilo.com

### G6 Mitte

WILO SE  
Vertriebsbüro Frankfurt  
An den drei Hasen 31  
61440 Oberursel/Ts.  
T 06171 70460  
F 06171 704665  
frankfurt.anfragen@wilo.com

### Kompetenz-Team Gebäudetechnik

WILO SE  
Nortkirchenstraße 100  
44263 Dortmund  
T 0231 4102-7516  
T 01805 R•U•F•W•I•L•O\*  
7•8•3•9•4•5•6  
F 0231 4102-7666

Erreichbar Mo-Fr von 7-18 Uhr.

- Antworten auf
  - Produkt- und Anwendungsfragen
  - Liefertermine und Lieferzeiten
- Informationen über Ansprechpartner vor Ort
- Versand von Informationsunterlagen

### Kompetenz-Team Kommune Bau + Bergbau

WILO EMU GmbH  
Heimgartenstraße 1  
95030 Hof  
T 09281 974-550  
F 09281 974-551

### Werkkundendienst Gebäudetechnik Kommune Bau + Bergbau Industrie

WILO SE  
Nortkirchenstraße 100  
44263 Dortmund  
T 0231 4102-7900  
T 01805 W•I•L•O•K•D\*  
9•4•5•6•5•3  
F 0231 4102-7126  
kundendienst@wilo.com

Erreichbar Mo-Fr von  
7-17 Uhr.  
Wochenende und feiertags  
9-14 Uhr elektronische  
Bereitschaft mit  
Rückruf-Garantie!

- Kundendienst-Anforderung
- Werksreparaturen
- Ersatzteilfragen
- Inbetriebnahme
- Inspektion
- Technische Service-Beratung
- Qualitätsanalyse

\* 14 Cent pro Minute aus dem deutschen Festnetz der T-Com. Bei Anrufen aus Mobilfunknetzen sind Preisabweichungen möglich.

### Wilo-International

#### Österreich

Zentrale Wien:  
WILO Pumpen Österreich GmbH  
Eitnergasse 13  
1230 Wien  
T +43 507 507-0  
F +43 507 507-15

Vertriebsbüro Salzburg:  
Gnigler Straße 56  
5020 Salzburg  
T +43 507 507-13  
F +43 507 507-15

Vertriebsbüro Oberösterreich:  
Trattnachtalstraße 7  
4710 Grieskirchen  
T +43 507 507-26  
F +43 507 507-15

#### Schweiz

EMB Pumpen AG  
Gerstenweg 7  
4310 Rheinfelden  
T +41 61 83680-20  
F +41 61 83680-21

### Standorte weiterer Tochtergesellschaften

Argentinien, Aserbajdschan,  
Belarus, Belgien, Bulgarien,  
China, Dänemark, Estland,  
Finnland, Frankreich,  
Griechenland, Großbritannien,  
Irland, Italien, Kanada,  
Kasachstan, Korea, Kroatien,  
Lettland, Libanon, Litauen,  
Niederlande, Norwegen,  
Polen, Portugal, Rumänien,  
Russland, Saudi-Arabien,  
Schweden, Serbien und  
Montenegro, Slowakei,  
Slowenien, Spanien,  
Südafrika, Taiwan,  
Tschechien, Türkei, Ukraine,  
Ungarn, Vereinigte Arabische  
Emirate, Vietnam, USA

Die Adressen finden Sie unter  
[www.wilo.de](http://www.wilo.de) oder  
[www.wilo.com](http://www.wilo.com).

Stand Februar 2009